

## SA-400 Stamp Application Unit



SA-400 Stamp Application Unit

The Stamp Application Unit SA-400 applies up to 400 tax stamps per minute on cigarette packs. The cigarette packs are continuously transported through the unit from left to right. The tax stamps are supplied from an adjustable magazine and will be applied, with hot melt, to the cigarette packs. The adjustable magazine allows a quick and simple change of the tax stamp format.

Positioning of the tax stamps: The SA-400 standard variant apply the tax stamp on the back or on the back and side of the cigarette pack.

Existing SA-400 can be adapted to meet the requirements from the EU Tobacco Directive. With a format kit the tax stamp can be applied on the small side or the small side and on top of the cigarette pack.

The compact design and integrated control cabinet allow a mobile use of the Tax Application Unit SA-400.

## Technical data

|                      |  |
|----------------------|--|
| Output:              | up to 400 packs / min. (with the standard variant) |
| Stamp length:        | 40 – 54 mm   |
| Stamp width:         | 12 – 29 mm   |
| Stamp type:          | with or without perforation                        |
| Packet length:       | 60 – 105 mm  |
| Packet width:        | 40 – 80 mm   |
| Packet height:       | 12 – 30 mm (other formats on request)              |
| Operating voltage:   | 400 V, 3-ph., 50 – 60 Hz                           |
| Power consumption:   | approx. 2.5 kW                                     |
| Compressed air:      | 5 – 8 bar  |
| Vacuum requirements: | approx. 12m <sup>3</sup> /h at 80 % vacuum         |
| Noise level:         | < 75 dB (A)  |
| Dimensions:          | 1325 x 760 x 1700 mm (L x W x H)                   |
| Weight:              | approx. 300 kg                                     |

Subject to alterations.